

READ AND SAVE THESE INSTRUCTIONS

# VAPOR-LOGIC<sup>®</sup><sub>2</sub>

## MICROPROCESSOR HUMIDIFIER CONTROL SYSTEM

### Installation Instructions and Maintenance Operations Manual



UL LISTED



CUL LISTED

**DRISTEEM<sup>®</sup>**



---

# TABLE OF CONTENTS

---

## TO THE PURCHASER AND THE INSTALLER:

Thank you for deciding to purchase the VAPOR-LOGIC<sub>2</sub><sup>®</sup> microprocessor-based humidifier control system. We have designed and developed this microprocessor to give you total satisfaction and many years of trouble-free service. Observing the installation and operating practices described in this manual will assure you of achieving that objective. We urge you to become familiar with the contents of this manual.

DRI-STEEM Humidifier Company

<b>Introduction</b>	
VAPOR-LOGIC <sub>2</sub> Microprocessor .....	3
<b>VAPOR-LOGIC<sub>2</sub> Control Board</b>	
Installation .....	4
Operation .....	4
<b>VAPOR-LOGIC<sub>2</sub> Key Pad / Digital Display</b>	
Operation .....	5
<b>Sensing Device Placement and Wiring</b>	
Placement .....	7
Control Precautions .....	7
Humidistats and Transmitters .....	8
<b>Proper Wiring Procedures .....</b>	<b>9</b>
<b>VAPOR-LOGIC<sub>2</sub> Auto Scroll Information .....</b>	<b>11</b>
<b>VAPOR-LOGIC<sub>2</sub> Main Menu Information .....</b>	<b>12</b>
<b>VAPOR-LOGIC<sub>2</sub> System Status Information .....</b>	<b>13</b>
<b>System Fault &amp; Disable Conditions .....</b>	<b>14</b>
<b>Maintenance Service Record .....</b>	<b>15</b>
<b>Warranty .....</b>	<b>16</b>

# INTRODUCTION

This manual explains the operation of and gives instructions for the use of the VAPOR-LOGIC<sub>2</sub> microprocessor (see figure 3-1).


VAPOR-LOGIC<sub>2</sub> is a custom microprocessor-based humidifier control system developed to be compatible with DRI-STEEM single stage humidifiers. (See Figures 3-2, 3-3 and 3-4 below.) The versatile software is configured to meet the needs of humidification system control variations and to adapt to a multitude of humidifier applications. The advanced technology of VAPOR-LOGIC<sub>2</sub> provides reliable operation while its simple operating procedures make it easy to use.

VAPOR-LOGIC<sub>2</sub> features include a self-diagnostic test during initialization, end-of-season drain, compatibility with most control inputs. A full-function integral digital display key pad that allows you to monitor and adjust humidifier performance parameters.


VAPOR-LOGIC<sub>2</sub> controls single stage humidification systems with control accuracies within  $\pm 3\%$  RH.




**Figure 3-1:** The key pad clearly displays the system function of the humidifier.



**Figure 3-2:** The VAPOR-LOGIC<sub>2</sub> key pad is mounted on the CRU humidifier control cabinet, located near the unit.



**Figure 3-3:** The VAPOR-LOGIC<sub>2</sub> key pad is mounted on the front of the HUMIDI-TECH<sup>®</sup> cabinet for easy access.



**Figure 3-4:** The STS and LTS humidifiers offer the flexibility of mounting the VAPOR-LOGIC<sub>2</sub> key pad on a control cabinet that is mounted either on the humidifier or on a wall near the humidifier.

# VAPOR-LOGIC<sub>2</sub> CONTROL BOARD INSTALLATION


The VAPOR-LOGIC<sub>2</sub> control board is shipped factory mounted within a control cabinet with all internal wiring completed. All software has been custom programmed into your VAPOR-LOGIC<sub>2</sub> system according to the original order requirements. Refer to the VAPOR-LOGIC<sub>2</sub> control board drawing for detail of the board and connection points. (See Figure 4-1.)

**Never run control system wires bundled with, or in the same conduit as, line voltage wires.**

**All humidifier power wiring is represented on the humidifier wiring diagram. A wiring diagram and information guide are attached to the inside of control cabinet door. All instructions should remain in the control cabinet after installation.**

## VAPOR-LOGIC<sub>2</sub> CONTROL BOARD OPERATION

**Figure 4-1: VAPOR-LOGIC<sub>2</sub> Printed Circuit Board**




OM-613

No.	Description	No.	Description
J1	Alphanumeric Display Module Connector	QC-5	FRZ Receives 2, 21 VDC Input From Freeze Stat
J2	Removable Terminal Strip to Reline Control Signals	QC-6	V10 Water Level, C
J3	Jumper PIN Selects Temperature Compensation Signal	QC-7	OR Water Level, B
J4	Jumper PIN Selects High Limit Humidity Signal	QC-8	BR Water Level, A
J5	Jumper PIN Selects Control Input Signal	QC-9	YEL Water Level Common
QC-1	Heat 24 Volt Output to Heater Contactor	QC-10	+SSR Modulating 6-9 VDC, DC Output
QC-2	Drain Drain Valve 24 Vac Output	QC-11	24H 24 Vac Hot
QC-3	Fill Fill Valve 24 Vac Output	QC-12	24H 24 Vac Hot
QC-4	+21V 21 Volt DC Output to Freeze Stat	QC-13	COM 24 Vac Common

# VAPOR-LOGIC<sub>2</sub> OPERATION

**Figure 5-1 : Conductivity Probes**



A conductivity probe system allows VAPOR-LOGIC<sub>2</sub> to control water levels for optimum operating efficiency. The three-probe system is monitored by the VAPOR-LOGIC<sub>2</sub> control, which performs all necessary logic and timing functions to provide total water level control and safety shutdown.

VAPOR-LOGIC<sub>2</sub> automatically maintains the water level between the upper two probes A and B. When the water level falls below probe B, the fill valve is opened until the water level reaches the upper probe A. (A two second delay is incorporated in the skim time software to ensure that turbulence does not cause an inaccurate fill reading.) An adjustable skim time allows for an extended skim period (2-60 seconds) to reduce mineral concentration within the humidifier. This adjustment can be accessed through the key pad main menu. (See page 7.) Probe C provides low water protection for the heating elements. If the water level falls below probe C, the heat source is de-energized. (See Figure 5-1.)

In addition to controlling the water level, VAPOR-LOGIC<sub>2</sub> determines when the heat source is energized. If there is a call for humidification, even during the fill cycle, the heat source will stay on to provide continuous output.

## Auto Drain Sequence

VAPOR-LOGIC<sub>2</sub> is pre-programmed to enter an automatic drain, flush, and refill cycle based upon the actual time the humidifier has produced steam. VAPOR-LOGIC<sub>2</sub> is factory-set for a 40 hour (accumulated "ON" time) drain interval, with 8 minute drain and 8 minute flush durations. When VAPOR-LOGIC<sub>2</sub> initiates the auto drain sequence, all demand for heat is turned off. The drain valve is then opened to allow the tank to drain. At the end of the drain cycle the fill valve is opened initiating the flush cycle. The drain valve remains open during the flush sequence for drainage while the fill valve is open. At the completion of the flush cycle, the drain valve closes, allowing the fill valve to refill the evaporating chamber. The VAPOR-LOGIC<sub>2</sub> timers are reset and the humidifier returns to normal AUTO operation.

## End of Season Drain


If there is not a call for humidification over a 72 hour period, VAPOR-LOGIC<sub>2</sub> automatically drains the humidifier. The drain valve is held open for one hour. The humidifier then switches into STDBY mode until there is a call for humidification, at which time VAPOR-LOGIC<sub>2</sub> automatically refills the evaporating chamber and resumes normal operation.

## VAPOR-LOGIC<sub>2</sub> KEY PAD / DIGITAL DISPLAY OPERATION

The system is provided with an LCD display that has two lines with sixteen characters per line. This display provides all of the control, monitoring, and setup information.

The key pad has four keys that are used to set and control the system: MODE, SET, and the UP & DOWN ARROW keys. (See Figure 5-2.)

**Figure 5-2:  
VAPOR-LOGIC<sub>2</sub> Key  
Pad/Digital Display**



## MODE

The MODE key is used to place the system into one of four operating modes. Each time MODE is pressed, the system will move to the next mode: AUTO, STANDBY, DRAIN, and TEST.

The other three keys are multifunction keys whose function depends upon the current system mode.

## SET

The SET key, if pressed while the system is in either AUTOMATIC or STANDBY mode, will place the system into the Main Menu. (Note: if Access Code Protection has been selected, an additional step is necessary. See page 7 for further information.) Once in the Main Menu, pressing SET will move the digital display through the various Main Menu parameters.

---

# VAPOR-LOGIC<sub>2</sub> KEY PAD / DIGITAL DISPLAY OPERATION

---

## UP ARROW

The UP ARROW key is used, in the AUTOMATIC mode, to transfer one of the automatic scrolling items on the lower line to the upper line for constant monitoring. The item selected will be updated every few seconds and will remain isolated on the upper line while the other functions will continue scrolling on the lower line. Items that can be selected for constant monitoring are: Actual RH, Actual High Limit RH, Glass Temperature, Time until Recommended Service, Time until Automatic Drain and Flush Sequence, and Time until End of Season Drain.

If the system is in the DRAIN mode, pressing the UP ARROW key will open the drain valve.

If the system is in the TEST mode, pressing the UP ARROW key will start the test, or continue the test if it was halted.

## DOWN ARROW

The DOWN ARROW key is used, in the AUTOMATIC mode, to sequence through the auto scrolling items of the lower line. (To see the list of auto scrolling parameters, turn to page 11.)

If the system is in the DRAIN mode, pressing the DOWN ARROW key will close the drain valve.

If the system is in the TEST mode, pressing the DOWN ARROW key will halt the test, or if already halted, will cancel the test.

## OPERATING MODES

There are four operating modes: AUTO, STANDBY, DRAIN, and TEST. These different modes allow you to monitor and control the various operations of VAPOR-LOGIC<sub>2</sub>. The digital displays vary considerably from mode to mode. The tables on pages 11-14 will give you all of the possible displays, as well as their descriptions, so you are able to understand what VAPOR-LOGIC<sub>2</sub> communicates through the digital display.

## AUTO MODE

The AUTO mode allows for the normal operation of the humidifier. AUTO mode is the default mode of VAPOR-LOGIC<sub>2</sub> if power is interrupted.

In AUTO mode the upper line contains the review parameter you have selected and the lower line contains the auto scrolling parameters. (Remember: the UP ARROW key can be used to move through the possible review parameters on the upper line, while the DOWN ARROW key can be used to scroll through the parameters listed on the lower line.)

## STANDBY MODE

When in STANDBY mode, the control outputs are turned off. Inputs continue to be monitored, and all programming functions are available. However, no outputs are affected, and the water level in the evaporating chamber is not maintained. The drain timers and service timers do not accumulate time.

## DRAIN MODE

Similar to the STANDBY mode, the inputs are monitored but no outputs are affected while the system is in DRAIN mode. Programming functions are not accessible while in the DRAIN mode. The DRAIN mode de-energizes the heat source. While in the DRAIN mode, the drain valve can be opened or closed with the UP and DOWN keys.

In DRAIN mode, the upper display will read DRAIN MODE while the lower display reads either DRAIN OFF or DRAIN ON.

## TEST MODE

The TEST mode can turn on the control outputs one at a time to verify that each is performing correctly. All other functions are blocked. The TEST mode begins with a flashing TEST MODE message for five seconds. After this delay, the outputs are cycled individually. The heat demand, the drain valve, and the fill valve are tested.

In TEST mode, the upper display will read TEST MODE while the lower display indicates the status of the test, or the output function being tested. For example, the lower line display could read: FILL ON.

## INITIALIZATION

When power is first applied to VAPOR-LOGIC<sub>2</sub>, a short self-diagnostics test sequence is performed. During this test, the microprocessor and the nonvolatile EEPROM memory are verified to be functioning properly. If a fault is detected, the fault message is displayed and humidifier operation stops. If no fault is detected, VAPOR-LOGIC<sub>2</sub> begins normal operation in the AUTO mode.

# VAPOR-LOGIC<sup>®</sup> 2 KEY PAD / DIGITAL DISPLAY OPERATION

## Accessing and Setting Main Menu Parameters

In either AUTO or STANDBY Mode, press the SET key to enter the Main Menu. (Note: The Access Code has been factory set to 00, and will not appear unless you have reset the Access Code. You may set the Access Code as you would any other parameter in the Main Menu.)

Once in the Main Menu, use the SET key to scroll through the items until the item you want is shown.

Use the UP and DOWN ARROW keys to change or set the parameter.

## SENSING DEVICE PLACEMENT AND WIRING

### Sensing Device Placement


The location of the humidity sensing devices is very important to achieve accurate humidity control. A drawing of a typical small air handling system is shown below (Figure 7-1). For the best control, place the humidity sensing device in the center of room, or just inside of the return air duct (location A). This will provide the least amount of variation caused by air flow patterns and room temperature. Placement of the duct high limit humidity sensing device (location D) must be downstream from dispersion tubes a sufficient distance to ensure steam absorption has taken place. Accurate control of temperatures in rooms and ducts is also very important to improve control of relative humidity.

### Control Precautions

Unsatisfactory humidifier control accuracy may involve more than just the controller's capability to control the system. Other factors that play an important role in overall system control are:

- Size of the humidification system.
- Overall system dynamics associated with moisture migration time lags.
- Accuracy of humidistats and humidity transmitters and their location.
- Dry bulb temperature accuracy in space or duct.
- Velocities and air flow patterns in ducts and space environments.
- Electrical noise or interference.

Figure 7-1: Humidistat Control or Humidity and Temperature Transmitters Recommended Placement



# SENSING DEVICE PLACEMENT AND WIRING

## Wiring On/Off Humidistats\*

DRI-STEEM may provide three types of on-off controls: a wall or a return air, duct-mounted humidistat, or a pneumatic/electric relay.

## Modulating Humidistats\*

Humidistats can be supplied for either wall or duct-mounted applications. These humidistats are powered by a 21 VDC supply provided by the VAPOR-LOGIC<sub>2</sub> control board. A 0-15 VDC modulated control signal is returned to the VAPOR-LOGIC<sub>2</sub> control board which modulates the output of the humidifier.

To use a signal from a pneumatic humidistat, DRI-STEEM can provide a transducer for a 20-138 kPa pneumatic input range. This pneumatic input is converted to a 0-135 Ohm signal. This 0-135 Ohm signal is adaptable to the VAPOR-LOGIC<sub>2</sub> control board.

\*(Humidity set-point is made at the humidistat.)

## Modulating Humidity Sensors with Transmitters

DRI-STEEM can supply sensors with transmitters for either wall or duct-mounted applications. They are powered by VAPOR-LOGIC<sub>2</sub> and have an output of 4-20 mA for a 0-100% RH range. (Humidity set-point is done at the VAPOR-LOGIC<sub>2</sub> keypad.)

### OPTION: Variable Air Volume (VAV) Control Kit

When this system is ordered, a second modulating humidity sensor with transmitter is supplied (for duct mounting). This transmitter limits humidifier output during periods of low air flow to prevent saturation of air being humidified.

**NOTE: The wiring diagram (found on the inside of the humidifier control cabinet) will show proper wiring for these controls.**

**NOTE: DRI-STEEM recommends using a 1 mm<sup>2</sup> plenum-rated shielded cable for transmitter wiring and grounding shield at a protective earthing bar in control cabinet. (See Figure 8-1.)**

### OPTION: Aquastat

This option protects the humidifier from damage due to freezing. Should the temperature of the water in the humidifier drop to near freezing the aquastat will energize the heat source as needed.

### OPTION: High Limit Controller

This option is recommended for all duct humidifier applications. It is usually set for 90 to 95% RH and protects the duct system from condensation due to a rise in duct RH or drops in air temperature or air volume.


### OPTION: Cold Snap RH Offset

This option prevents condensation from forming on windows during periods of frigid weather. It consists of a transmitter mounted on an appropriate window to sense glass temperature. When the glass temperature falls below the dew point, the RH set point is automatically lowered. When the cold snap ends and the glass temperature rises, the normal RH set-point is automatically restored.

### Cold Snap Transmitter Placement (See Figure 9-1)

1. Position the cold snap transmitter control box on a wall adjacent to lower window framing and route the temperature sensor umbilical cord behind the wall and out through window framework.
2. Place flat surface of temperature sensor tip on lower corner of glass surface.
3. Temporarily hold sensor tip in place with strips of masking tape.
4. Apply small amount of clear RTV silicone adhesive over and around the sensor tip (making sure the sensor tip is in contact with the window glass).
5. After adhesive has cured, remove masking tape.


Figure 8-1: Shielded Cable





# SENSING DEVICE PLACEMENT AND WIRING

Figure 9-1: Cold Snap Transmitter Placement



## PROPER WIRING PROCEDURES

Electrical noise is generated by electrical equipment, such as switching loads, electric motors, solenoid coils, welding machinery, fluorescent light circuits, etc. These stray electrical currents can produce undesirable effects in the electronic control circuits that eventually affect controllability. The electrical noise or interference generated from these sources (and the effects on controllers) is very difficult to define, but most common symptoms are erratic operation or intermittent problems.


However, most noise problems can be prevented by using wiring practices and techniques which do not allow for coupling or inducing of electrical interference into control circuits. Some simple wiring practices associated with DRI-STEEM humidifier equipment should minimize interaction of noise and controls:

- Humidifier and control cabinets must be connected to a code-approved earth ground.
- When routing electrical wiring inside the control cabinet, separate line voltage wiring from low voltage control circuit wiring.
- Use separate metallic electrical conduits or cable trays for line and low voltage wiring from the humidifier to humidity sensors, airflow switches, etc.
- Do not mix chassis or safety grounds with current carrying commons. No safety grounds should ever be used as a conductor or neutral to return circuit current.
- The preferred method of external electrical connections to humidistats, room/duct humidity and temperature transmitters, and control signal input connections from building control systems is minimum size 1 mm<sup>2</sup> plenum rated wire cable of twisted pair type, BELDEN #8870, including cable shielding and drain wire for grounding.
- All grounding of shielded cable connections should be returned to the control cabinet and tied to the protective earthing bar. Do not ground shield at the device end.

**Note: Do not use shielded cable for probe wiring.**

# PROPER WIRING PROCEDURES

Figure 10-1: Earth Bar Wiring



For maximum E.M.C. effectiveness, all humidity, temperature and air flow controls should be wired using multi-conductor shielded plenum-rated cable with a drain wire for the shield. The drain wire should be connected to the shield ground terminal with its length kept to less than 50 mm.

## VAPOR-LOGIC<sup>®</sup><sub>2</sub> AUTO SCROLL INFORMATION

The following pages contain information about the digital read-outs that VAPOR-LOGIC<sub>2</sub> displays on the key pad. This includes a wide variety of present system conditions, faults, and programmable parameters that ultimately control the humidification system. The charts are organized based upon when or why the information is communicated.

### Auto Scroll

The items that will continuously scroll on the lower line during normal humidifier operation are listed below. The current conditions are monitored and communicated through VAPOR-LOGIC<sub>2</sub>. The items available for individual review on the upper line are noted.

AUTO SCROLL DESCRIPTION	AUTO SCROLL READ-OUT (LOWER LINE DISPLAY)	AVAILABLE FOR UPPER LINE REVIEW
Relative Humidity Set Point	"DESIRED RH __%"	NO
Actual Relative Humidity	"ACTUAL RH __%"	YES
Maximum High Limit Humidity	"MAX HL RH __%"	NO
Actual High Limit Humidity	"ACT HL RH __%"	YES
Window Glass Temperature	"GLASS TEMP ±__°C"	YES
Total Percentage System Output	"SYS DEMAND __%"	NO
Time until Service Message Display (in hours)	"SERVICE __H"	YES
Time until Automatic Drain and Flush (in hours)	"AUTO DRAIN __H"	YES
Time until End of Season Drain (in hours)	"EOS DRAIN __H"	YES
Setpoint Temperature Compensation Reduction	"TEMP COMP __%"	NO

## VAPOR-LOGIC<sup>®</sup><sub>2</sub> MAIN MENU INFORMATION

### Main Menu Descriptions

The Main Menu items are available by pressing the SET key while in either AUTO or STNDBY mode. The SET key also allows you to scroll through the items in the Main Menu. While in the Main Menu, you may view or change the system parameters by following the instructions on page 7.

Note: If any of the options were not selected by the original customer humidifier order, that specific parameter would be removed from the Main Menu.

If parameter values are changed, they take effect immediately, without waiting for the EEPROM SAVE to affect the system operation. (EEPROM= Electronically Erasable Programmable Read Only Memory Chip.)

The following is a list of the parameters, their setting ranges, and their default settings.

MAIN MENU DESCRIPTION	MAIN MENU READ-OUT	RANGE	FACTORY SET DEFAULT
Message Scan Delay Time*	"SCAN TIME __S"	0-10 seconds	0 seconds
Relative Humidity Setpoint	"DESIRED RH __%"	20-95%	35%
Maximum High Limit Humidity	"MAX HL RH __%"	20-95%	100%
Automatic Drain and Flush Interval	"ADS INT __H"	0-99 hours	40 hours
Automatic Drain Duration*	"ADS DUR __M"	0-30 minutes	8 minutes
Automatic Flush Duration*	"AFS DUR __M"	0-30 minutes	8 minutes
Access Code To Allow Set Up*	"ACC CODE ____"	0-9999	00
Time Proportioning Interval	"CYCLE RATE __S"	4-60 seconds	60 seconds
Proportional Band	"PROP BAND __%"	2-20%	10%
Reset (Integral) Interval*	"RESET __.M"	0-19.9 minutes	0.5 minutes
Skim Time	"SKIM TIME __S"	2-60 seconds	2 seconds
Calibration Offset for RH	"CAL RH ±__%"	-10% - + 10%	0%
Calibration Offset for HL RH	"CAL HL RH ±__%"	-10% to +10%	0%
Calibration Offset for Temperature	"CAL TEMP ±__°C"	-10°C to +10°C	0°C

\* These parameters, if set to zero, will eliminate the function from the humidification system. You may re-select the function at any time by changing the parameter in the Main Menu to a value other than zero.

## VAPOR-LOGIC<sup>®</sup><sub>2</sub> SYSTEM STATUS INFORMATION

DIGITAL DISPLAY SYSTEM STATUS READ-OUT	SYSTEM STATUS DESCRIPTION
"AUTO MODE"	The system is in AUTO MODE, which allows for the normal operation of the humidifier. (Default mode at start-up.)
"STANDBY MODE"	The system is in STANDBY MODE, which turns off all control outputs during periods of servicing. Programming functions are available. Electric power must be shut off at the disconnect before servicing electrically heated humidifiers.
"DRAIN MODE"	The system is in DRAIN MODE, which turns off all control outputs during periods of servicing. Programming functions are not available.
"TEST MODE"	The system is in TEST MODE, which is used to verify the performance of the individual control outputs.
"DRAIN ON"	The Automatic or Manual Drain has been activated, during normal operating procedures.
"FLUSHING"	The system is in the Flush Interval of the Auto Drain sequence.
"EOS DRAIN ACTIVE"	The humidifier has not been active for 72 hours and has activated the End-of-Season Drain.
"FILL ON"	The Fill Valve has been activated.
"AQUASTAT ENABLE"	The heater has been enabled or activated by the aquastat.
"BEGINNING TEST"	When the test cycle has been initially activated, this pre-test message appears.
"HEAT OFF"	This designates part of the Heater Output test: heater contactor/valve has been turned off.
"HEAT ON"	This designates part of the Heater Output test: heater contactor/valve has been turned on.
"DRAIN OFF"	This designates part of the Drain Output test: drain valve has been closed.
"DRAIN ON"	This designates part of the Drain Output test: drain valve has been opened.
"FILL OFF"	This designates part of the Fill Output test: fill valve has been closed.
"FILL ON"	This designates part of the Fill Output test: the fill valve has been opened.
"SERVICE"	DRI-STEEM recommends inspecting and, if necessary, cleaning your humidifier system at this time.

## SYSTEM FAULT & DISABLE CONDITIONS

### Fault Conditions

The system continuously monitors for a wide variety of FAULT conditions. When a FAULT occurs, the status of the system is changed to FAULT and the appropriate description appears in the lower line display. A FAULT condition shuts off all humidifier outputs.

All faults deactivate the demand for heat. If the fault is a FILL fault, the line voltage must be interrupted to reset the system. All other faults are AUTOMATIC RESET, and the fault will automatically clear once the condition no longer exists and the system then proceeds as normal.

SYSTEM FAULT READ-OUT	SYSTEM FAULT DESCRIPTION	RECOMMENDED ACTION
"FAULT SYSTEM ERROR"	A failure condition has been detected during self-diagnostics test. (Microprocessor or EEPROM fault.)	Consult DRI-STEEM.
"FAULT LIQUID LEVEL SEN"	An error has been detected in the sequencing of the probe.	Clean probe rod assembly.
"FAULT FILL TIMER OVER"	The FILL has not been completed during the set FILL time. (Tank is not full.)	Check water supply shut off valve. Check inline strainer. Check for voltage present at the valve (when filling).
"FAULT DRAIN FAULT ACT"	The DRAIN has not been completed during the set DRAIN time. (Tank is not empty.)	Check for plugged tank drain outlet, clean. Check for voltage present at the valve (when in DRAIN mode).
"FAULT SENSOR"	The RH Transmitters or Temperature Transmitter have detected invalid readings (too low).	Check for open, shorted, or incorrect wiring.

### Disable Conditions

The humidifier may be disabled by three conditions. These disabling conditions are not faults as they are expected to occur in normal operation of the system. They are temporary interruptions to the normal operation of the humidifier. They are indicated by a message on the second line of the display. Once the condition has been corrected the humidifier will resume operation automatically.

SYSTEM DISABLE READ-OUT	SYSTEM DISABLE DESCRIPTION	RECOMMENDED ACTION
"AFPS DISABLE"	The Air Flow Proving Switch has detected too little air flow.	Check for proper air flow: blowers, filters, coils, etc.
"HL RH DISABLE"	The actual duct relative humidity has exceeded the programmed upper limit.	Check for low duct temperature and proper air flow.
"LO WATER DISABLE"	A low water level has been detected in the tank.	Check water supply.



## TWO YEAR LIMITED WARRANTY

DRI-STEEM Humidifier Company ("DRI-STEEM") warrants to the original user that its products will be free from defects in materials and workmanship for a period of two (2) years after installation or twenty-seven (27) months from the date DRI-STEEM ships such product, whichever date is the earlier.

If any DRI-STEEM product is found to be defective in material or workmanship during the applicable warranty period, DRI-STEEM's entire liability, and the purchaser's sole and exclusive remedy, shall be the repair or replacement of the defective product, or the refund of the purchase price, at DRI-STEEM's election. DRI-STEEM shall not be liable for any costs or expenses, whether direct or indirect, associated with the installation, removal or re-installation of any defective product.

DRI-STEEM's limited warranty shall not be effective or actionable unless there is compliance with all installation and operating instructions furnished by DRI-STEEM, or if the products have been modified or altered without the written consent of DRI-STEEM, or if such products have been subject to accident, misuse, mishandling, tampering, negligence or improper maintenance. Any warranty claim must be submitted to DRI-STEEM in writing within the stated warranty period.

DRI-STEEM's limited warranty is made in lieu of, and DRI-STEEM disclaims all other warranties, whether express or implied, including but not limited to any IMPLIED WARRANTY OF MERCHANTABILITY, ANY IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE, any implied warranty arising out of a course of dealing or of performance, custom or usage of trade.

DRI-STEEM SHALL NOT, UNDER ANY CIRCUMSTANCES BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, LOSS OF PROFITS, REVENUE OR BUSINESS) OR DAMAGE OR INJURY TO PERSONS OR PROPERTY IN ANY WAY RELATED TO THE MANUFACTURE OR THE USE OF ITS PRODUCTS. The exclusion applies regardless of whether such damages are sought based on breach of warranty, breach of contract, negligence, strict liability in tort, or any other legal theory, even if DRI-STEEM has notice of the possibility of such damages.

By purchasing DRI-STEEM's products, the purchaser agrees to the terms and conditions of this limited warranty.

# DRI-STEEM®



14949 Technology Drive • Eden Prairie, MN 55344  
Phone: (800) 328-4447 (952) 949-2415 • Fax: (952) 229-3200  
E-Mail: sales@dristeem.com • Web: www.dristeem.com

**Europe Office:**

Bell Place, Bell Lane • Syresham, Brackley • NN13 5HP, U.K.  
Phone: +44 1280 850122 • Fax: +44 1280 850124  
E-Mail: 106277.1443@compuserve.com